



START / FLAMEOUT SWITCH			
	•	•	
	•		

MAIN SWITCH			
	•	•	•
	•	•	•
	•	•	•

TURNING SWITCH			
L	•	•	•
OFF	•	•	•
R	•	•	•

HORN SWITCH	
ON	•
OFF	•
R/R	•

HIGH/LOW BEAM SWITCH	
BL	•
DC	•
W	•

BRAKE SWITCH	
ON	•
OFF	•
B	•

COLOR INDICATION:

RED: R, BLACK: B, BLUE: BL, PALE GREEN: PG
 WHITE: W, YELLOW: Y, GREEN: G, PURPLE: P
 BROWN: BR, GREY: GR, SKAY BLUE: SB
 ORANGE: O, DARK GREEN: DG
 SHORT CIRCUIT: